

## Sistema de alarma de seguridad digital. Inalámbrico

### CE200F

El CE200F es un sistema de alarma para el hogar que detecta intrusiones y fuego. Está programado para enviar mensajes de voz y llamar a los números predeterminados por el usuario, cuando detecta algún intruso o fuego dentro de la casa. Adicionalmente usted puede controlar los sonidos y asustar al intruso con la función de altavoz.



**1. ALTAVOZ**

**2. TECLADO**

**3. MICRÓFONO**

**4. SENSOR DE INTRUSIÓN**


**5. SENSOR DE FUEGO**

**6. BOTÓN DE EMERGENCIA**



#### Características

- Llama hasta 5 números de teléfonos designados
- 24 horas de vigilancia de intrusión e incendios, sin cuotas mensuales
- Verificación de control de sonido y voz de alerta desde lugares remotos
- Active y desactive el sistema desde cualquier teléfono
- Intrusión, incendio, de gas, de emergencia, la falta de energía
- Indicador de batería baja con pantalla LCD y mensaje de voz
- Compatible con el uso de todas las líneas de comunicación (Tono, pulso, ADSL y RDSI)
- Llamada de emergencia se pueden realizar incluso si el teléfono o la línea de fax está ocupado
- Se puede armar el perímetro: función útil para mantener a las mascotas en la casa
- Despues de la confirmación, el sistema puede ser desactivado para detener el ciclo de llamadas
- Modo de prueba para una fácil instalación


### Aplicaciones




Rango de detección



Conexión a la pared



### Conexión al teléfono



### Especificaciones

ITEM	CYBEREYE
MODEL	CE-200F
Function	Intrusion
	O
	Fire
	O
	Emergency
	O
	Power Failure
Detection Range	O
	Gas Leakage(option)
	O
	Life Sensor (option)
	X
	Car sensor (option)
	O
Detection Range	Detection distance 8 m( Horizontal: 90°, Vertical: 23° )
Detecting Temperature	Above 60°C
Phone No. Entry	8
Memory Phone No. Entry	X
Information Confirmation	LCD + Voice
Voice Range	X
Voice Alarm	For Activated Sensors
Voice Message	Location and Emergency type
Wireless Range	100m (Depends on the obstacles)
	AC adaptor (DC 9V Rechargeable Back-up battery)
Power	204 X 96 X 60mm
Size	490g
Weight	Refer to Optional sensors' specifications
Options	

### Opciones

Item	Contents
<b>Wireless Motion Sensor (BS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects an intruder or a fire.
<b>Wireless Door Sensor (DS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects an intruder entering through a door or a window.
<b>Wireless Siren (SR-200F)</b>	
	It sounds a loud alarm (105dB) when it receives a signal from a remote control, emergency switch or other optional sensors
<b>Wireless Emergency Switch (ES-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when the emergency switch is pressed.
<b>Wireless Smoke Sensor (SS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects a fire.
<b>Wireless Smoke Sensor (SS-300F)</b>	
	It sounds an alarm and activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects a fire.
<b>Wireless Gas Sensor (GS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects gas leakage.
<b>Wireless Window Sensor (WD-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects a window breakage or impact.
<b>Wrist Transmitter (WS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when the emergency button is pressed.
<b>Pendent Transmitter (PR-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when the emergency button is pressed.
<b>Wireless Outdoor Sensor (OS-200F)</b>	
	It activates the Cybereye, wireless siren and wireless emergency lamp with radio wave when it detects an intruder outdoors.
<b>Wireless Emergency Lamp (LP-200F)</b>	
	It blinks and sounds an alarm when it receives a signal from the optional sensors or emergency button is pressed.
<b>Wireless Emergency Lamp (LP-300F)</b>	
	It blinks and sounds an alarm when it receives a signal from the optional sensors or emergency button is pressed. (Back up battery)
<b>Security Digital Camera System (IC-100A, IC-300C)</b>	
	Image capture when it detects an intruder.